

Temperature controllers for single room applications with one analog output:

- The analog output ao1 can be used in VAV applications to contol one or more VAV controllers.
- · In change-over applications, the analog output ao1 can be changed over from cooling to heating mode via an input.



Device variants

Type CR24-A1, same functionality as the

		CR24-B1 but without an operator panel.	
Technical data			
Electrical data	Nominal voltage	AC 24 V 50/60 Hz	
	For wire sizing	3 VA, without actuators	
	Power supply range	AC 19.228.8 V	
	Connections	Terminal block 13: 2.5 mm ²	
Functional data	Control phase stavistics	Terminal block 48: 1.5 mm ²	
Functional data	Control characteristics	•	
	P-band heating / cooling Fytograph temporature conser (cit)	Selectable: 1.5 / 1.0 K or 3.0 / 2.0 K	
	External temperature sensor (ai1)	Type NTC, $5 \text{ k}\Omega$, sensing range $1045 ^{\circ}\text{C}$ for example Belimo type TFK	
	Heating setpoint	Range 1536°C (default 21°C)	
	Energy hold off	Heating 15°C / cooling 40°C	
	- Stand-by	Heating –2 K / cooling +3 K	
	Dead band	1 K	
	Frost limit temperature	10°C	
	Operation (CR24-B only)		
	 Mode switch and status indication (LEDs) 	AUTO (green) - ECO (orange) - MAX (red)	
	 Rotary knob for setpoint adjustment 	±3 K	
	Communication port for field devices	2 x PP (for PC-Tool, MFT remote control etc.)	
Inputs	2 x analog, 2 x digital		
	 External temperature sensor (ai1) 	Type NTC, 5 kΩ, sensing range 1045°C	
	 External setpoint shift (ai2) 	010 V corresponds to 010 K	
	 Digital inputs (di1, di2) 	Contact rating 10 mA	
Outputs	1 x analog		
	VAV system output (ao1)	(0)2 10 V, max. 5 mA	
Norms und standards	Protection class	III Safety extra-low voltage	
	Degree of protection	IP 30 to EN 60529	
	Mode of operation	Type 1 to EN 60730-1	
	Software class	A to EN 60730-1	
	EMC	CE conformity to 89/336/EEC	
	Ambient conditions		
	Operation	0+50°C / 2090% rH (without condensation	
	 Transport and storage 	-25+70°C / 2090% rH (without condensation	
Dimensions / Weight	Dimensions (H x W x D)	99 x 84 x 32 mm	
	Weight	105 g	
Housing colors	Baseplate	NCS2005-R80B light gray	
· ·	•	(corresponds approx. to RAL 7035)	
	Cover	RAL 9003-Signalweiss	

Safety notes



- · The controller is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- It may only be installed by suitably trained personnel. All applicable legal or institutional installation regulations must be complied with.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.

The device contains electrical and electronic components and is not allowed to be disposed of as household refuse. All locally valid regulations and requirements must be observed.



Product features

Energy hold off

In energy saving mode, the room temperature is reduced to building protection level, i.e. either the heating setpoint is significantly reduced or the cooling setpoint is significantly increased, for

instance in a room with an open window.

The room temperature is reduced to stand-by level, i.e. either the heating setpoint is slightly Stand-by

reduced or the cooling setpoint is slightly increased, for instance in a room that is temporarily unoccupied.

The frost protection function is activated if the actual room temperature falls below 10°C. Frost

Change-over heating or heating/cooling. Change-over

External temperature sensor An external temperature sensor can be connected to the analog input ai1, for instance in order

to measure the average room temperature in the exhaust air duct.

An external DC 0...10 V signal at the analog input ai2 can be used to shift the basic setpoint **External setpoint shift**

0...10 K, for instance for the summer/winter compensation.


These functions are described in detail on pages 17 to 24.


Configuration / Principal diagramm

Configuration



DIP	Default settings	
1	P-band normal	P-band wide
2	Input di2 Stand-by	Input di2 Change-over






Key				
Y [V]	Output voltage in volt	V _{max}	Maximum volume flow	
t _R [°C]	Room temperature in degrees centigrade	V _{min}	Minimum volume flow	
W _H	Heating setpoint			
Wc	Cooling setpoint]		

Electrical installation

Wiring diagram

Notes

- · Connect via safety isolation transformer.
- · Parallel connection of other actuators possible. Note the performance data.



Inputs		Outputs			
3	ai1	External temperature sensor	6	ao1	System output for Belimo VAV controller
٥	di1	Energy hold off	Other connections		nections
4	di2	Stand-by / Change-over	7	PP1	Diagnostics socket 1
5	ai2	External setpoint shift	8	PP2	Diagnostics socket 2