

Modulating linear actuators for adjusting air dampers and slide valves in ventilation and air conditioning systems in buildings

- For air dampers up to approx. 3 m<sup>2</sup>
- · Actuating force 450 N
- Nominal voltage AC/DC 24 V
- Control: modulating DC 0 ... 10 V, position feedback DC 2 ... 10 V
- Lenght of stroke
   100 or 200 mm, fixed



Overview of types					
	Туре	Stroke	Operating range	Weight	
	SH24A-SR100	100 mm, fixed	DC 2 10 V ~ 0 100 mm	1.08 kg	
	SH24A-SR200	200 mm, fixed	DC 2 10 V ~ 0 200 mm	1.15 kg	
Technical data					
Electrical data	Nominal voltage		AC 24 V, 50/60 Hz DC 24 V		
	Power supply rang	ge	AC/DC 19.2 28.8 V		
	Power consumption	At rest	2 W @ nominal force 0.4 W		
	0	For wire sizing	4 VA	0	
	Connection		Cable 1 m, 3 x 0.75 mm		
Functional data	Actuating force		450 N @ nominal voltag		
	Control Control signal Y Operating range			DC 0 10 V, typical input impedance 100 kΩ See «Overview of types»	
	Position feedback (Measuring voltage U)			DC 2 10 V, max. 1 mA	
	Position accuracy	· •	±5%		
	Stroke		See «Overview of types	»	
	Direction of stroke at Y = 0 V  Running time  Sound power level		**	Reversible with switch 1₹ resp. 0±	
			150 s / 100 mm	<u>'</u>	
			<50 dB (A)		
Safety	Protection class		III Safety extra-low volta	ge / UL Class 2 Supply	
	Degree of protecti	on	IP54 in any mounting po		
			NEMA 2, UL Enclosure	7.	
	EMC		-	CE according to 2004/108/EC	
	Certification		and CAN/CSA E60730-		
				30-1 and IEC/EN 60730-2-14	
	Mode of operation Rated impulse voltage Supply		Type 1		
			0.8 kV		
	O t	Control	0.8 kV		
	Control pollution degree Ambient temperature range Non-operating temperature Ambient humidity range		3 -30 +50°C		
			−40 +80 °C 95% r.H., non-condensa	ating	
	Maintenance	ı any <del>c</del>	Maintenance-free	ung	
	wamenance		ivianilendine-nee	iviaintenance-free	

Dimensions / Weight


Dimensions


Weight


See «Dimensions» on page 3


See «Overview of types»

























AC 24 V / DC 24 V















## Safety notes



- The actuator is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- It may only be installed by suitably trained personnel. Any legal regulations or regulations issued by authorities must be observed during assembly.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The rotary supports and coupling pieces available as accessories must always be used if lateral forces are likely. In addition, the actuator must not be tightly bolted to the application.
   It must remain movable via the rotary support (refer to «Assembly notes»).
- If the linear actuator is exposed to severely contaminated atmosphere, appropriate
  precautions must be taken on the system side. Excessive deposits of dust, soot etc. can
  prevent the gear rack from being extended and retracted correctly.
- If not installed horizontally, the gear disengagement pushbutton may only be actuated when there is no pressure on the gear rod.
- To calculate the actuating force required for air dampers and slide valves, the specifications supplied by the damper manufacturers concerning the surface, cross section, design, installation site and the air flow conditions must be observed.
- If a rotary support and/or coupling piece is used, losses in the actuation force losses are to be expected.
- The device contains electrical and electronic components and is not allowed to be disposed
  of as household refuse. All locally valid regulations and requirements must be observed.

# **Product features**

Mode of operation

The actuator is controlled with a standard modulating signal of DC  $0\dots 10$  V and moves to the position defined by the control signal. The measuring voltage U serves for the electrical display of the damper position  $0\dots 100\%$  and as slave control signal for other actuators.

Manual override

Manual override with push-button possible (the gear is disengaged for as long as the button is pressed or remains locked).

High functional reliability

The actuator is overload-proof, requires no limit switches and automatically stops when the end stop is reached.

### **Accessories**

	Description	Data sheet
Electrical accessories	Electrical accessories Positioner SGA24, SGF24 and SGE24	
	Range controller SBG24	T2 - SBG24
	Digital position indication ZAD24	T2 - ZAD24
Mechanical accessories	Rotary support to compensate lateral forces Z-DS1	T2 - Z-SHA
	Coupling piece Z-KS1	T2 - Z-SHA
	Mechanical limiter set Z-AS1	T2 - Z-SHA


## **Electrical installation**

## Wiring diagram

#### Notes

- Connect via safety isolating transformer.
- Other actuators can be connected in parallel.

  Please note the performance data!



Direction of stroke




- 1 = black
- 2 = red3 = white
- 5 = orange



# **Dimensions [mm]**

#### **Dimensional drawings**



Туре	Max. Stroke	Α	В
SH24A-SR100	100	233.5	294.7
SH24A-SR200	200	333.5	394.7

## **Assembly notes**

Application without transverse forces

The linear actuator is screwed directly to the housing at three points. Afterwards, the head of the gear rod is fastened to the moving part of the ventilation application (e.g. damper or slide valve).

Application with transverse forces

The coupling piece with the internal thread (Z-KS1) is connected to the head of the gear rod. The rotary support (Z-DS1) is screwed to the ventilation application. Afterwards, the linear actuator is screwed to the previously mounted rotary support with the

attached to the moving part of the ventilation application (e.g. damper or slide valve).

# Caution If a rotary support and/or coupling piece is

used, losses in the actuation force losses are to be expected.

coupling piece. The maximum permissible swivel angle of the rotary support and coupling piece If the stroke limitations are used on the gear rod, the mechanical working range can be exploited from an extension length of 20 mm.

enclosed screw. Afterwards, the coupling piece, which is mounted to the head of the gear rod, is

The transverse forces can be compensated for to a certain limit with the rotary support and/or

Stroke limitation